



OUTLAW AG SERIES

TURNSTILE MAINTENANCE INSTRUCTIONS

Annual Recommended Inspection and Maintenance for AG Series Turnstiles

- Remove the lid from the header.
- Clean out the header of any dust and debris.
- Take out center shaft by lifting it out of the top of the locking mechanism (you may need a pair of channel locks to grip the shaft).
- Add grease when reinserting the shaft, for ease of future maintenance.
- Lift the center rotor off of the bearing, inspect bearing, re-grease with red grease or replace if necessary. Make sure that the rotor is oriented properly with the arms facing the middle / center of the cage. If replacement is necessary the bottom bearing part number is AGRB10.
- Test electrical function by triggering turnstile to unlock in each direction.
- Shut off the equipment breaker in the header of the turnstile, make sure that fail-open and fail-close are functioning properly.
- If your turnstile is equipped with lights, verify that all directional lights are working properly, replace bulbs or module as necessary.