

1

2

3

4

D

D

| | |
|-------------|-----|
| FIRST DRAWN | BY |
| 01-19-22 | CJC |
| REVISED | BY |
| | |
| | |

COPYRIGHT © TURNSTILES.US
 Copyright © Turnstiles.us All rights reserved. Reproduction or translation of this work without the express written permission of TURNSTILES.US is unlawful and is an infringement of intellectual property belonging to TURNSTILES.US.
 All drawings and/or designs are restricted for use exclusively with a purchase, installation, and/or support from Turnstiles.us. Any other use of these materials is a violation of copyright law. Request for additional information should be addressed to the Legal Department, Turnstiles.us.

EntraPASS Global Redundancy Server



EntraPASS Global Workstation



Ethernet Cable

Network Switch by others

KT-400 #1

KT-400 #2

Reader Cable TYP.

iClass Reader

iClass Reader

iClass Reader

Reader Cable TYP.

QR500 Reader

QR500 Reader

QR500 Reader

mWing Series

FINISHED FLOOR

ADA Lane

ADA Lane

ADA Lane

ELEVATION

TURNSTILES.US
 www.TURNSTILES.us
 Call 303 670 1099 * Text 303 918 9787
 patrick.mcallister@turnstiles.us

| | |
|--|--------------------------------------|
| Wiring - Single Line Detail | |
| Resort World Las Vegas Tesla Tunnel Station mWing Series, iClass & QR Readers KT-400 and EntraPASS Global | |
| DWG | 01-19-22 RWLV TESLA TUNNEL SLD |
| DATE | 01-19-22 |
| SHEET - 1 OF 1 | |

1

2

3

4

A

A